

6-Outlet Outdoor Power Stake with Timer - 9ft

Model 402051-9

User Manual

(Available in a PDF file)

Email: support@cablematters.com

Contents

1.INTRODUCTION	L
1.1 Introduction	L
1.2 Copyright and Trademarks	L
2. PRODUCT OVERVIEW	Ł
2.1 Product Description1	L
2.2 Product Features	L
3. CONNECTION AND OPERATING INSTRUCTIONS	2
3.1 Installation	2
3.2 Programming	2
4. TECHNICAL SPECIFICATIONS	3
5. WARRANTY AND SUPPORT	4
5.1 Customer Support and Contact Information	4
5.2 Warranty Information	ł
5.3 Limitation of Liability4	4

1. INTRODUCTION

1.1 Introduction

Thank you for your purchase from Cable Matters® Inc., the 'Reliable Connectivity' company. This User Manual provides an overview of the features and installation of the

6-Outlet Outdoor Power Stake with Timer - 9ft

Please read these instructions carefully before installing, operating, or configuring this product. Please keep this user manual for future reference.

Contact support@cablematters.com for questions or product support.

1.2 Copyright and Trademarks

Specifications are subject to change without notice. Cable Matters is a registered trademark or trademark of Cable Matters Inc. All rights reserved. All other trademarks are the property of their respective owners.

2. PRODUCT OVERVIEW

2.1 Product Description

Introducing the Cable Matters 6-Outlet Outdoor Power Stake with Timer, the perfect solution for managing your outdoor lighting and appliances with ease and convenience.

2.2 Product Features

 Six Outlets: With six outlets, this power stake provides ample space to connect multiple devices simultaneously, allowing you to power various outdoor lights, decorations, and appliances from a single source.

Built-in Timer: The integrated timer feature allows you to schedule your outdoor devices to turn on and
off automatically at your preferred times. Choose from settings such as always on, always off, dusk-todawn, or set specific durations of 2, 4, 6, or 8 hours.

Durable Construction: Crafted with weather-resistant materials, this outdoor power stake is built to withstand harsh outdoor conditions, ensuring reliable performance year-round.

3. CONNECTION AND OPERATING INSTRUCTIONS

3.1 Installation

1. Join the two segments of the yard stake together.

Securely attach the yard stake to the timer body by twisting it into the underside. Ensure a firm connection between the stake and the timer body.

- 3. Insert the stake into the ground, burying it at least 6 inches deep for stability.
- 4. Connect the yard stake to a 3-conductor GFCI protected outlet.
- 5. Plug your lights or appliances into the timer, leaving them in the "ON" position for operation.

3.2 Programming

Rotate the dial on the timer to select from the following settings:


- · OFF (always off)
- · ON (always on)
- · DUSK-DAWN (turns on at dusk, off at dawn)
- 2, 4, 6, or 8 HRS (turns on at dusk for 2, 4, 6, or 8 hours)

Note:

 The 2hr, 4hr, 6hr, 8hr, and Dawn-Dusk modes will activate at dusk. Please ensure to position the yard stake away from other sources of light to prevent any potential impact on the start time.

 Once the timer activates at dusk in the 2hr, 4hr, 6hr, or 8hr mode, it will complete its cycle regardless of external factors. Headlights, porch lights, and street lamps will not disrupt the ongoing timer program.

• The timer will reset upon unplugging the power stake.



4. TECHNICAL SPECIFICATIONS

Plug Type: 1x NEMA 5-15P Socket Type: 6x NEMA 5-15R Waterproof: Yes Operating temperature: -4 to 104°F Overload protection: Yes Cord Length: 9 feet Cord Color: Green Certification: ETL Wire Type: 14 AWG Heavy Duty SJTW Wire Voltage: 125V Maximum Current (A), Power Rating (W): Resistive Load: 15A, 1875W Tungsten Load: 10A, 1250W Motor Load: 1/2 HP

CAUTION: Risk of Fire. Not for Permanent Installation.

This product is intended for temporary outdoor use only. It is designed to be used with outdoor equipment, Christmas trees, or other seasonal decorative lighting products with a maximum total load of 15 Ampere. Do not use this product for more than a 90-day period.

When connecting Christmas tree or decorative lighting products that do not have a marked ampere rating, ensure that no more than 140 screw-base lamps (C7 or C9) or 12 strings with midget (push-in) lamps are connected to this cord set.

For safety, all cord sets must be plugged into a GFCI-protected receptacle.

If you plan to use an outdoor-use cord set for an extended period (greater than 90 days), it is advisable to consider hardwiring a permanent outdoor-use receptacle rated for year-round use in the area where power is needed. For proper installation of permanent wiring, please contact a licensed electrician.

After installation, ensure that the connector always remains a minimum of 6 inches above ground level.

www.cablematters.com

5. WARRANTY AND SUPPORT

5.1 Customer Support and Contact Information

Cable Matters offers lifetime technical support as an integral part of our commitment to provide industry leading solutions.

Email us with any questions at support@cablematters.com.

5.2 Warranty Information

This product is backed by a limited one-year warranty. The warranty covers parts and labor costs only. Cable Matters does not warrant its products from defects or damages arising from misuse, abuse, or normal wear.

5.3 Limitation of Liability

In no event shall Cable Matters Inc. (including their officers, directors, employees or agents) be liable for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of, or related to the use of this product exceeding the actual price paid for the product (as allowed by state law).